



Gateway Pro
iPod, USB, Bluetooth

User Manual

Opel CAN (OC2)

v.1.0

GWP-9207-1

1. INTRODUCTION

The Dension Gateway Pro lets you connect your iPod or USB storage (stick, hard drive or mass storage capable mp3 player) to your original car radio, providing music playback, menu based control and charging.

The Gateway Pro offers Bluetooth connectivity for music streaming (via A2DP) and handsfree mobile call handling via the original buttons and screens of your vehicle.

Supported USB devices

USB: Flash Memory and Hard Disk Drive (UBS1.1 and higher)

File System: FAT16 or FAT32

Storage capacity: up to 320 GB music content

Music Format: MP3, WMA and WAV, OGG

Supported iPod / iPhone devices

iPod (4th generation)

iPod nano (1st, 2nd, 3rd, 4th, 5th and 6th generation)

iPod mini

iPod Photo 4G

iPod Video 5G

iPod Classic

iPod Touch (1st, 2nd, 3rd and 4th generation)

iPhone, iPhone 3G / 3GS, iPhone 4 / 4S

Aux: 3.5mm stereo aux input (optional)

2. GETTING STARTED

Switch on your car radio and **select AUX mode** by pressing the 'CD/AUX' button.

Connect your iPod or USB storage to the Gateway. It will start playing the first song on the device. If the Gateway has been in use earlier, music will play from your iPod or USB from the point at which they last played.

When switching off the radio the playback will stop and the source devices will go to standby if the ignition key is removed.

You can pair the Gateway Pro with a Bluetooth capable mobile phone for music streaming (requires an A2DP capable phone) or handsfree use (if that option is active in the Gateway). Pairing is controlled from the mobile phone the same way as connecting to other Bluetooth accessories. The pin code to the Gateway Pro is **0000** (for further details read **Section 4**).

Accessing the Menu

The menu of the Gateway Pro is displayed on the main screen. Due to the capabilities of your car, the Gateway Pro menu is **not visible** on the cluster display (between the two main instruments).

11:48 Themes - I Sound, II 02:01 ▶ 22°C
RDS CD MP3 ROM AUX



The music playback and settings are controlled from the radio. **Please note:** steering wheel buttons are **not functional except the volume** and the **mute** buttons.

3. OPERATION

You can enter the Gateway Pro's main menu by pressing the "Folder +" button or the "Multifunctional button" on the Head Unit. Use the "Multifunctional button" for browsing, turn right or left for accessing different menu options.

In order to select a menu item press the Folder + or the "Multifunctional button" or press "Folder -" to return to the previous level.

If song selected the currently played song's title visible on the display. In order to see Album or Artist info, press the 'INFO' button on the Head Unit.



- **Music** (for iPod only): Allows browsing and selecting music in the sub-menus: **Playlist, Artists, Albums, Titles, Genres, Composers, Audiobooks, Podcasts**.

11:51 Albums RDS CD 21°C

When an artist is selected the PLAY menu item plays all the songs from the given artist, the ALL menu lists all the songs from the given artists. The albums from the artist are listed as separate items afterwards.

When an album is selected, all the songs from the given album are listed as separate items afterwards.

The following menu items available in the main menu serve as specific functions for music playback:

- **Play All:** plays all the music from the selected source. The playback starts from the first song on the device.
- **Album play:** Plays the full album of the song being played, typically used when in random play mode.

Settings menu

Volume

The volume menu allows you to set the different volumes in the system:

- iPod, USB, Aux, Bluetooth volumes for music playback
- Phone and microphone volume for handsfree calls

Phonebook

In the phonebook menu you can switch off the automatic download of the phone book, which is required to work with certain phone models.

BT Audio

You can turn the BT Audio option ON if you want to play music from mobile phone via A2DP

Paired phone

Last four paired phone name (ID) will be listed here. You can force pairing from this menu too if you click select the phone from the list

About

Provides information on the gateway product (SW versions, serial number, etc.).

11:50 Artists RDS CD 21°C

4. HANDSFREE OPTION

Connecting a Phone

You can pair a Bluetooth capable mobile phone for handsfree calls. This can be the same device as the one paired for music streaming or you can have a separate phone paired for handsfree calls. Such pairing is possible by setting the Bluetooth connection type in the devices accordingly. The connection types are: handsfree profile (HFP) and music streaming (A2DP).

Please note: that not all Bluetooth capable mobile phones support setting the Bluetooth connection type. Such phones typically pair for handsfree and music streaming (if supported).

Turn on the Bluetooth option, search for available devices, **select Gateway Pro** and **enter 0000** for connection. When a phone is connected you can see the connection status on the phone screen.

Using the Phone Menu

In order to reach phone functions, press the 'PHONE' button on the Head Unit then press the "Multifunctional Button" or the "Folder +" button to enter the phone menu. Use the "Multifunctional button" for browsing, turn right or left for accessing different menu options. Press "Multifunctional button" or "Folder +" to enter a submenu or press "Folder -" to return to the previous level.



In the phone menu you will see the following menu items.

- **Phonebook:** you can select a phone number from your address book to initiate a call. Contacts are shown in alphabetical groups, followed by all contacts in alphabetical order.
- **Received / Missed / Dialled Call:** provides access to the respective call logs.



- **DISCONNECT:** Disconnects the paired phone.

Please note that for consistency reasons the Gateway Pro does not store the phone numbers therefore your phone is synchronized every time it connects to the gateway. **Synchronization is possible for up to 1000 phone numbers only from the phone's memory** (entries with multiple phone numbers synchronize as multiple entries).

Receiving and Making Phone Calls

When receiving an incoming call, the caller number (if provided) or the corresponding contact names in your phone book are displayed on the radio display. You can answer the call by pressing the "Multifunctional button" on the Head Unit. The music or radio gets muted and the audio of the call is directed to the speakers.



You can reject an incoming call by pressing the 'BACK' button

To initiate a call, please select the phone number or contact from the Phonebook or call logs in the Phone menu and press the "Multifunctional button".



You can hang up an ongoing call if you press the "Multifunctional button".

5. CONFIGURATION SWITCHES (DIP)

You can find DIP switches on the bottom of the Gateway Pro. You can activate / deactivate options with DIP switches like Bluetooth. Turn **DIP switch #5 ON** in order to **disable the phone** option of the Gateway Pro (e.g. if you want to use the factory fitted phone). For further details, please read the installation guide.

6. CONNECTOR PORT

Connector port (EXT1CP2) is an accessory for Gateway Pro. This device gives the following specific functions:

- Aux-input
- USB extension
- Bypass selector
- Status LED
- Reset switch



7. DISCLAIMER AND WARRANTY

Disclaimer

If your car's electrical system begins to behave erratically, please disconnect the Gateway interface physically immediately and have it checked by your installer. Dension and its authorized distributors and retailers are not liable for any incidental consequential or indirect damages or loss and do not assume liability for any diagnostic fees.

The use of handheld devices while driving may be subject to government legislation. Please ensure that your use of the Dension device complies with applicable traffic laws. Dension does not assume liability for any events resulting from the illegal or irresponsible use of handheld devices while driving.

Dension reserves the right to modify its products or specifications without prior notice.

Warranty

Dension devices carry a one-year limited warranty that protects you from defects in material and workmanship of products sold by Dension or its authorized distributors and retailers. Dension does not warrant any installation work or assume liability for any damage caused due to negligence, improper installation or operation. For warranty claims, proof of purchase is required.

Further assistance

If you need further assistance in using your Dension product, please contact your local supplier or visit www.dension.com and click on 'Support'.

Please check the download section for the latest firmware version and product documentation, as these may provide additional features or easier use of the product.